



HX1 Bluetooth Stereo Headset

Ref. nr.: 130.115



INSTRUCTION MANUAL

ENGLISH

Congratulations to the purchase of this Max product. Please read this manual thoroughly prior to using the product in order to benefit fully from all features.

Read the manual prior to using the product. Follow the instructions in order not to invalidate the warranty. Take all precautions to avoid fire and/or electrical shock. Repairs must only be carried out by a qualified technician in order to avoid electrical shock. Keep the manual for future reference.

- Prior to using the product, please ask advice from a specialist. When the unit is switched on for the first time, some smell may occur. This is normal and will disappear after a while.
- The unit contains voltage carrying parts. Therefore do NOT open the housing.
- Do not place metal objects or pour liquids into the product. This may cause electrical shock and malfunction.
- Do not place the product near heat sources such as radiators, etc. Do not place the unit on a vibrating surface. Do not cover the ventilation holes.
- The product is not suitable for continuous use.
- Be careful with the mains lead and do not damage it. A faulty or damaged mains lead can cause electrical shock and malfunction.
- When unplugging the product from a mains outlet, always pull the plug, never the lead.
- Do not plug or unplug the unit with wet hands.
- If the plug and/or the mains lead are damaged, they need to be replaced by a qualified technician.
- If the product is damaged to such an extent that internal parts are visible, do NOT plug the unit into a mains outlet and DO NOT switch the product on. Contact your dealer. Do NOT connect the product to a rheostat or dimmer.
- To avoid fire and shock hazard, do not expose the product to rain and moisture.
- All repairs should be carried out by a qualified technician only.
- Connect the product to an earthed mains outlet (220-240Vac/50Hz) protected by a 10-16A fuse.
- During a thunderstorm or if the product will not be used for a longer period of time, unplug it from the mains. The rule is: Unplug it from the mains when not in use.
- If the product has not been used for a longer period of time, condensation may occur. Let the unit reach room temperature before you switch it on. Never use the product in humid rooms or outdoors.
- During operation, the housing becomes very hot. Do not touch it during operation and immediately after.
- To prevent accidents in companies, you must follow the applicable guide lines and follow the instructions.
- Secure the product with an extra safety chain if the unit is ceiling mount. Use a truss system with clamps. Make sure nobody stands in the mounting area. Mount the effect at least 50cm away from inflammable material and leave at least 1 meter space on every side to ensure sufficient cooling.
- This product contains high intensity LEDs. Do not look into the LED light to prevent damage to your eyes.
- Do not repeatedly switch the product on and off. This shortens the life time.
- Keep the unit out of the reach of children. Do not leave the unit unattended.
- Do not use cleaning sprays to clean switches. The residues of these sprays cause deposits of dust and grease. In case of malfunction, always seek advice from a specialist.
- Only operate the product with clean hands.
- Do not force the controls.
- If the product has fallen, always have it checked by a qualified technician before you switch the product on again.
- Do not use chemicals to clean the unit. They damage the varnish. Only clean the product with a dry cloth.
- Keep away from electronic equipment that may cause interference.
- Only use original spares for repairs, otherwise serious damage and/or dangerous radiation may occur.
- Switch the product off prior to unplugging it from the mains and/or other equipment. Unplug all leads and cables prior to moving the product.
- Make sure that the mains lead cannot be damaged when people walk on it. Check the mains lead before every use for damages and faults!
- The mains voltage is 220-240Vac/50Hz. Check if power outlet match. If you travel, make sure that the mains voltage of the country is suitable for this product.
- Keep the original packing material so that you can transport the product in safe conditions



This mark attracts the attention of the user to high voltages that are present inside the housing and that are of sufficient magnitude to cause a shock hazard.



This mark attracts the attention of the user to important instructions that are contained in the manual and that he should read and adhere to.



DO NOT LOOK DIRECTLY INTO THE LENS. This can damage your eyes. Persons who are subject to epileptic attacks should be aware of the effects that this light effect may have on them.

The product has been certified CE. It is prohibited to make any changes to the product. They would invalidate the CE certificate and their guarantee!

NOTE: To make sure that the unit will function normally, it must be used in rooms with a temperature between 5°C/41°F and 35°C/95°F.



Electric products must not be put into household waste. Please bring them to a recycling centre. Ask your local authorities or your dealer about the way to proceed. The specifications are typical. The actual values can slightly change from one unit to the other. Specifications can be changed without prior notice.

Do not attempt to make any repairs yourself. This would invalid your warranty. Do not make any changes to the product. This would also invalid your warranty. The warranty is not applicable in case of accidents or damages caused by inappropriate use or disrespect of the warnings contained in this manual. Max cannot be held responsible for personal injuries caused by a disrespect of the safety recommendations and warnings. This is also applicable to all damages in whatever form.

UNPACKING INSTRUCTION

CAUTION! Immediately upon receiving the product, carefully unpack the carton, check the contents to ensure that all parts are present, and have been received in good condition. Notify the shipper immediately and retain packing material for inspection if any parts appear damage from shipping or the package itself shows signs of mishandling. Save the package and all packing materials. In the event that the product must be returned to the factory, it is important that the product be returned in the original factory box and packing.

If the device has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your device. Leave the device switched off until it has reached room temperature.

Product Overview



1 Power on/off/Play/Pause/Hands-free	<ul style="list-style-type: none"> a. Long press to power on or power off b. Short press to receive or end calls, play or pause music.
2 Indicator	<ul style="list-style-type: none"> a. Under Bluetooth pairing mode, blue and red LED flash quickly. b. While headphone is being charged, red LED turns on. When charging completes, red LED turns off and blue LED turns on.
3 Microphone	
4 Volume up/down	<ul style="list-style-type: none"> a. Volume up button: short press to increase volume, long press to move to next track. b. Volume down button: short press to decrease volume, long press to go back to last track.
5 Micro USB charging connector	
6 Ear bud	

Bluetooth

Turn on headphone, Bluetooth works spontaneously, searching previous pairing Bluetooth set. If headphone fails to connect, it starts pairing other Bluetooth devices. In this case, turn on your Bluetooth device to search headphone. PIN code is "0000". Music streams after pairing successfully. When headphone is connected with mobile phone, you can short press "POWER" to receive calls, long press "POWER" to reject calls, if there is incoming call.

Charging

Plug the charging cable into Micro USB slot of headphone, USB slot of PC or other USB slot of chargers to get charged. When the headset is being charged, red LED turns on. When charging completes, red LED turns off and blue LED turns on. (We'd suggest the users turning off while charging. It takes longer time to get fully charged if it works when being charged.)

Warnings

1. If headphone cannot on after switching on, or it turns off on turning on, please check whether it is powered. If it's out of power, please get it charged and try again later.
2. Please get headphone charged with DC 5V adaptor or USB slot of PC. It would make headphone fail to work or even damage headphone if not charged in recommended voltage.
3. If Bluetooth device of Mobile Phone, PC etc fails to link to headphone or if fails to playing music after being connected, the user shall check if he/she enters the correct PIN code or if Bluetooth device of his/her Mobile Phone, PC etc supports A2DP.

Specification

Bluetooth version	V3.0
Wireless connection	≤5-10 meters
Power supply	DC 5V/3.7V
Battery	3.7V 60mAh polymer battery
Playing time	≤4 hours at max volume
Frequency	20Hz-20KHz
Driver	10mm
Charging connector	Micro USB connector
Material	PC+ABS plastic



tronios
Sound & Light

CE Declaration of Conformity

Manufacturer: TRONIOS BV
Bedrijvenpark Twente 415
7602 KM – ALMELO
+31(0)546589299
+31(0)546589298
The Netherlands

Product number: 130.115

Product Description: HX1 Bluetooth Stereo Headset

Trade Name: MAX

Regulatory Requirement: EN 62479
EN 60065
EN 50332
EN 301 489 V.1.9.2
EN 301 489-17 V2.2.1
EN 300 328 V1.9

I hereby declare that the product meets the requirements stated in Directives 2014/35/EU and 2014/30/EU and conforms to the above mentioned Declarations.

Almelo,

22-02-2017

Name : *M. Velders*

Signature :

Specifications and design are subject to change without prior notice..

www.tronios.com

Copyright © 2017 by TRONIOS the Netherlands